

















# GEOMETRICAL TOLERANCING IN PRACTICE


Home / Geometrical Tolerancing in Practice

## Form tolerances according to ISO 1101


<p><b>— Straightness</b></p>  <p>The tolerance zone is limited by two parallel lines at a distance <math>t</math> apart. Every envelope line of the tolerated cylinder must be between these two parallel lines.</p> <p><b>Example</b> Every envelope line of the tolerated cylinder surface must be between two parallel lines at a distance apart of 0.1.</p> 	<p><b>○ Roundness</b></p>  <p>The tolerance zone is limited by two concentric circles at a distance <math>t</math> apart. The circumference line of the tolerated cylinder must be within a circle ring of the zone width <math>t</math>, in every radial section plane.</p> <p><b>Example</b> The circumference line of the tolerated cylinder must be within a circle ring of the zone width 0.1 in every radial section plane.</p> 
<p><b>▭ Flatness</b></p>  <p>The tolerance zone is limited by two parallel planes at a distance <math>t</math> apart, the dimensions of which correspond to those of the tolerated area. The real workpiece area must be between the two parallel planes at distance <math>t</math> apart.</p> <p><b>Example</b> The real workpiece area must be between two parallel planes at a distance apart of 0.2.</p> 	<p><b>○⊂ Cylindricity</b></p>  <p>The tolerance zone for the cylinder envelope area limits the deviation of the roundness, the straightness of the envelope line and the parallelism of the envelope line to the cylinder axis. It is formed by two coaxial cylinders with the radial distance <math>t</math>.</p> <p><b>Example</b> The tolerated cylindrical area must be between two coaxial cylinders with a radial distance of 0.1.</p> 

## Position tolerances according to ISO 1101


<p><b>// Parallelism</b></p>  <p>The tolerance zone within which the envelope lines of the tolerated cylinder must lie is limited by two parallel lines at a distance <math>t</math> apart which run parallel to the datum plane.</p> <p><b>Example</b> Every single envelope line of the tolerated area must be between two parallel lines that are at a distance of 0.1 apart, and are parallel to the center axis.</p> 	<p><b>⊥ Perpendicularity</b></p>  <p>The tolerance zone is limited by two parallel planes at a distance <math>t</math> apart, which are perpendicular to the datum axis. The tolerated plane face must be between these two planes.</p> <p><b>Example</b> All points/circle lines of the tolerated area must be between two parallel planes that are at a distance of 0.1 apart, and are perpendicular to the datum plane.</p> 
<p><b>∠ Angularity</b></p>  <p>The tolerance zone is limited by two parallel planes at a distance <math>t</math> apart at the nominal angle to the datum axis.</p> <p><b>Example</b> All points of the tolerated area must be between two parallel planes that are at a distance apart of 0.1, and are angled at 20° to the datum axis.</p> 	<p><b>◎ Coaxiality</b></p>  <p>The tolerance zone is limited by a cylinder of diameter <math>t</math>, the axis of which matches the datum axis. The actual axis of the tolerated element must be within the tolerance zone.</p> <p><b>Example</b> The axis of the tolerated cylinder must be within a cylinder that has a diameter of 0.1 and is coaxial to the datum axis A.</p> 




perpendicular to the surface, the tolerance zone is limited by two concentric circles at a distance  $t$  apart, the common center point of which is on the datum axis. The radial run-out tolerance applies generally for a full revolution of the tolerated element around the datum axis.



of every radial section plane of the tolerated cylindrical area must be between two concentric circles at a distance apart of 0.1 with their common center point on the datum axis A.




every radial distance of two circles at a distance  $t$  apart. The circles are in a cylinder, the axis of which matches the datum axis. The diameter of the cylinder can adopt any value of the diameter of the plane face.




toleranced area must be between two parallel circle planes at a distance apart of 0.1 with their common center point on the datum axis A.

### Total radial run-out




The tolerance zone is limited by two coaxial cylinders at a distance  $t$  apart, the axes of which match the datum axis. After several rotations around the datum axis and axial shift of the transducer all points of the tolerated element must be within the tolerance zone.

#### Example




The tolerated cylindrical area must be between two coaxial cylinders with a radial distance apart of 0.1 with their common axis on the datum axis A.

### Total axial run-out



The tolerance zone is limited by two parallel planes at a distance  $t$  apart, which are perpendicular to the datum (rotational) axis. After several rotations around the datum axis and radial shift of the transducer, all points of the surface of the tolerance plane face must be within the tolerance zone.

#### Example



The tolerated area must be between two parallel circle planes at a distance apart of 0.1 with their common center point on the datum axis A.

## General tolerances according to ISO 2768

### Tolerance class H

Nominal dimension range	> 10 ...30	> 30 ...100	> 100 ...300	> 300 ...1000	> 1000 ...3000	
	0.02	0.05	0.1	0.2	0.3	0.4
		0.2		0.3	0.4	0.5
			0.5			
			0.1			

For workpieces produced by cutting  
All dimensions in mm

### Tolerance class K

Nominal dimension range	> 10 ...30	> 30 ...100	> 100 ...300	> 300 ...1000	> 1000 ...3000	
	0.05	0.1	0.2	0.4	0.6	0.8
		0.4		0.6	0.8	1.0
			0.6		0.8	1.0
			0.2			

### Tolerance class L


Nominal dimension range	> 10 ...30	> 30 ...100	> 100 ...300	> 300 ...1000	> 1000 ...3000	
	0.1	0.2	0.4	0.8	1.2	1.6
		0.6		1.0	1.5	2.0
		0.6		1.0	1.5	2.0
			0.5			

Tolerance value corresponds to the diameter tolerance or maximum general tolerance for the radial run-out.  
 Tolerance value corresponds to the maximum value in comparison of the dimension tolerance of the distance dimension with the general tolerance for the straightness or the flatness of the form elements being inspected.


## Standards of practical relevance

### For measurement of roundness, straightness and flatness


ISO 1101	Geometrical Product Specifications (GPS) – Geometrical tolerancing – Tolerances of form, orientation, location and run-out
ISO 12180-1	Geometrical Product Specifications (GPS) – Cylindricity Part 1: Vocabulary and parameters of cylindricity
ISO 12181-1	Geometrical Product Specifications (GPS) – Roundness Part 1: Vocabulary and parameters of roundness
ISO 12780-1	Geometrical Product Specifications (GPS) – Straightness Part 1: Vocabulary and parameters of straightness
ISO 12781-1	Geometrical product specifications (GPS) – Flatness Part 1: Vocabulary and parameters of flatness
VDI/VDE 2631 Sheet 1	Form measurement – Basic principals of the determination of form and positional deviations
VDI/VDE 2631 Sheet 2	Form measurement – Determination of the sensitivity of the signal transmittal chain
VDI/VDE 2631 Sheet 3	Form measurement – Filter characteristics and selection




**MZCI**  
**Minimum Zone Circle**  
 Concentric inner and outer perimeter circles with a minimum radial distance, and which enclose the roundness profile.  
 Individual profile peaks influence the center point **considerably**.  
 Gives the least possible form error.




**LSCI**  
**Least Square Circle**  
 Circle through the roundness profile with minimum sum of profile deviation squares.  
 Individual profile peaks influence the center point **only a little**.  
 Very suitable for stable datum formation.




**MIC**  
**Maximum Inscribed Circle**  
 Maximum circle inscribed in the roundness profile for inside areas.  
 The method is used for form measurement of the inside diameter.




**MCCI**  
**Minimum Circumscribed Circle**  
 Minimum circle circumscribing the roundness profile for outside areas.  
 The method is used for form measurement of the outside diameter.




No filter  
 1.49  $\mu\text{m}$   
 RONt (MZCI) = 1.49  $\mu\text{m}$



Filter 150 W/R  
 1.04  $\mu\text{m}$   
 RONt (MZCI) = 1.04  $\mu\text{m}$




Filter 50 W/R  
 0.91  $\mu\text{m}$   
 RONt (MZCI) = 0.91  $\mu\text{m}$



Filter 15 W/R  
 0.71  $\mu\text{m}$   
 RONt (MZCI) = 0.71  $\mu\text{m}$

## ring entries

### Tolerance frame



### Toleranced elements

Indicating arrow to contour line or subsidiary line (offset from dimension line): if the tolerance refers to the line or area.  
 Indicating arrow as an extension of the dimension line: if the tolerance applies for the axis or median plane or a point of the element.



### Datums

Datum triangle with datum letters on the contour line of the element or on the subsidiary line: if the displayed datum is a line or area.  
 as an extension of the dimension line: if the datum is the axis, the median plane or an appropriately dimensioned point.  
 Restriction of the datum to an area of the element as a dot-dash line with dimensioning.  
 A filled or empty datum triangle has the same meaning.



## SHARE THIS:

Share 0 Share Tweet Save 1

# Leader in Rubber & Plastic Products

### CONTACT US

US: (626) 965-9966  
 F: (626) 581-2335  
 sales@CoiRubber.com  
 19255 San Jose Avenue Unit D-1  
 City of Industry, CA 91748

### SEARCH

Search..

### CUSTOMER FEEDBACK

...and offshore pricing and US ser was exactly what we have been looking

### MONTHLY NEWSLETTER

Don't miss out on updates!

Sign up for our mailing list:

email address

Subscribe

Translate »

### TRANSLATE:

COPYRIGHT © 2013 COI RUBBER PRODUCTS, INC. 19255 SAN JOSE AVENUE UNIT D-1, CITY OF INDUSTRY, CA 91748. ALL RIGHTS RESERVED / [TERMS OF USE](#) / [PRIVACY POLICY](#) / [SITEMAP](#) ALL OTHER TRADEMARKS, TRADE NAMES, SERVICE MARKS AND LOGOS REFERENCED HEREIN BELONG TO THEIR RESPECTIVE COMPANIES.

